


## Information Bulletin #2022-1

**Problem:** Information in the User Manual regarding the charging cycles is not clear/not present, which is the charge controller behaviour during this process.

**Solution:** An Information Bulletin should be issued to include the missing information.

**Equipment:** Hybrid Boost PWM charge controllers and Hybrid Boost MPPT charge controllers.

### 1. Hybrid Boost PWM charge controller.



**Battery Type:** Not relevant

**Manufacturer:** Not relevant

**Nominal Voltage:** 12V (as an example)

**Maximum charging Voltage:** 14.4V (as an example – usually supplied by the battery manufacturer – this value is extremely important! )



**INFO:** If you do not know which model is, it is easily identified by its front face. It has 4 navigation buttons, and the Brake LED is near the Silentwind Logo on top.

#### SETTING PARAMETERS:

**Absorption:** 13,4V

**Overvoltage:** 16V (not relevant for the charging cycle – it must be always higher than the maximum charging voltage)

**Storm Brake:** 32A (not relevant for the charging cycle)

**Low Wind Boost:** 2V (not relevant for the charging cycle)

**P.S:** The remaining parameters are for the Outputs 1&2. They do not interfere on the charging process neither on the charging cycle behaviour.



It is assumed that the wind generator produces energy, and all the parameters are correct.


### Charging cycle:



**Battery Status: Low**




**Charge Controller Status: Normal**



**Battery Status: 13,4V**




**Charge Controller Status: Brake**  
LED starts to blink.



**Battery Status: Full = 14,4V**



**Charge Controller Status: Brake**  
always ON. Not charging



**Battery Status: Discharging -**  
Voltage equal or higher than 13,1V



**Charge Controller Status: Brake**  
always ON. Not charging




**Battery Status:** 13,1V reached



**Charge Controller Status:** Brake waiting cycle of 10 minutes. The brake will be released afterwards.  
Brake LED = OFF - Battery < 13,1V

## 2. Hybrid Boost MPPT charge controller.



**Battery Type:** Not relevant

**Manufacturer:** Not relevant

**Nominal Voltage:** 12V (as an example)

**Maximum charging Voltage:** 14.4V (as an example – usually supplied by the battery manufacturer – this value is extremely important! )



**INFO:** If you do not know which model is, it is easily identified by its front face. It has 1 single “Scan” button and the Brake LED is near the button.

### SETTING PARAMETERS:

**End Of Charge Voltage:** 14,4V

**Overvoltage:** 16V (not relevant for the charging cycle – it must be always higher than the maximum charging voltage)

**Storm Brake:** 32A (not relevant for the charging cycle)

**Low Wind Boost:** 3V (not relevant for the charging cycle)

**P.S:** The other additional parameters are for the Outputs 1&2. They do not interfere on the charging process neither on the charging cycle behaviour.



It is assumed that the wind generator produces energy, and all the parameters are correct.


### Charging cycle:



**Battery Status: Low**




**Charge Controller Status: Normal**



**Battery Status: 13,4V**




**Charge Controller Status: Normal**



**Battery Status: Full = 14,4V**



**Charge Controller Status: Brake  
always ON. Not charging**



**Battery Status: Discharging -  
Voltage equal or higher than 13,1V**



**Charge Controller Status: Brake  
always ON. Not charging**



**Battery Status:** 13,1V reached



**Charge Controller Status:** Brake waiting cycle of 10 minutes. The brake will be released afterwards.  
Brake LED = OFF

### 3. Recovery voltage

| Nominal Voltage        | Recovery voltage (RV) | Max. Voltage parameter (MV) - Example | Recovery Point = MV - RV |
|------------------------|-----------------------|---------------------------------------|--------------------------|
| 12V Charge Controllers | 1.3V                  | 14.4V                                 | 13.1V                    |
| 24V Charge Controllers | 2.6V                  | 28.8V                                 | 26.2V                    |
| 48V Charge Controllers | 5.2V                  | 57.6V                                 | 52.4V                    |



**Additional Information:** When the batteries are connected to an external alternator, the charge controller might enter in Brake mode. Example: When a fuel energy generator is charging the batteries.